

# INSTALLATION MANUAL

65648T


ecotrackspot



120-240V | 50/60Hz | 30W | IP20 | Aluminium | Adjustable


Complete with 700mA driver.

90  
CRI




one  
LIGHT

1




To mount the track adaptor into the track system, first check that the selector knob **A** is at OFF position and the adaptor lock **B** is disengaged.

2




When installing the adaptor into the track, ensure that it is orientated correctly.

3




Rotate adaptor lock **B** clockwise 90° to lock the adaptor into the track system.


4



**Circuit 1:** To connect on circuit 1, from OFF position, rotate the knob **A** clockwise to position 1.



**Circuit 2:** To connect on circuit 2, from OFF position, rotate the knob **A** anti-clockwise to position 2.



**Circuit 3:** To connect on circuit 3, from OFF position, rotate the knob **A** anti-clockwise to position 3.

## Warnings:

1. Make sure that the product is installed properly before connecting to electricity.
2. Do not cover the fitting.
3. Maintenance and installation should only be carried out by a professional electrician.